

FUSE



To download your language go to www.side-power.com





SLEIPNER MOTOR AS

P.O. Box 519 N-1612 Fredrikstad Norway www.side-power.com

Document id: 6454


Revision: 2

Date: 2020



Fitting the fuse into the fuseholder

To avoid heating and voltage drop, it is very important that the fuse/fuseholder is assembled exactly as shown here with the fuse between the contact plates.



Warranty statement

- Warranty statement

 1. The equipment manufactured by Sleipner Motor AS (The "Warrantor") is warranted to be free from defects in workmanship and materials under normal use and service.

 2. This Warranty is in effect for of two years (Leisure Use) or one year (Commercial use) from the date of purchase must be included, to establish that it is inside the warranty period.

 3. This Warranty is transferable and covers the product for the specified time period.

 4. nace are purches to the equipment proves to be defective, to ther than those parts excluded in paragraph 5 below, the owner should do the following:

 (a) Prepare a detailed written statement of the nature and circumstances of the defect, to the best of the Owner's knowledge, including the date of purchase, the name and address of the installer, and the Purchaser's name, address and telephone number:

 (b) the Owner should return the defective part or unit along with the statement referenced in the preceding paragraph to the warrantor. Supplier Motor AS or an authorized Service Centre, postage/shipping prepaid and at the expense of the Purchaser; and the Purchaser and the Pur